

How to auto-program your flat screen TV:

If your TV is a flat screen you probably **DO NOT** need a cable box.

You do need to do an auto-program or auto search to find the Expanded on Demand channels in a digital format on AUGUST 11th!!

Please check your owner's manual for more detailed information.

Or follow the procedures below:

- Access the TV set menu from your television's remote control
- Go to the "Channel" or "Set-Up" mode
- Select the Auto Program or Channel Scan feature
- Choose the "Cable" setting (not antenna or Air)
- If asked, select the "STD" or Standard setting (not HRC)
- Start the scan mode

If your TV is not a flat screen TV, **YOU DO NEED A CABLE BOX!**

This information is also available on our website: norwoodlight.com